
## Remote Battery Monitoring – System Block Diagram



## Remote Battery Monitoring – Application Features

- ➤ The Central monitoring unit (CMU) creates configuration of location and their batteries and associates each config. with a picture of the location.
- > CMU will send alarm messages, through SMS to a specified mobile number in a human readable form.
- ➤ It will escalate the alarm status to higher officials based on hierarchy: Up-to 4 levels if the error is not rectified within a specified period of time.
- The Status can also be polled from the CMU

